

https://flairespresso.com/neo-flex-tutorials







- 1. QR Code for Video Tutorials
- 2. What's Included in the Box
- 3. Assembling your NEO Flex
- 4. Flow-Control vs. Bottomless 2-in-1 Portafilter
- 5-6. Brewing with your NEO Flex
- 7. Dialing-In Lever Force
- 8. Cleaning your NEO Flex
- 9. Troubleshooting Your NEO Flex

QR Code for Video Tutorials

Scan the code below to view video tutorials for your NEO Flex. Seeing is believing and is the best way to learn to brew beautiful espresso with your Flex.






What's Included in the Box

- 1 Main Post & Lever
- 2 Base
- 3 Piston with Training Disc (found inside brew cylinder)
- 4 Brew Cylinder
- **5** Stainless Steel Dispersion Screen (found inside brew cylinder)
- **6** Flow Control Portafilter (red)
- **⚠** Silicone Preheat Cap
- 8 Extra Flow-Control Spout
- 9 Dosing Cup/Tamper
- Funnel
- 11 Bottomless 2-in-1 Portafilter (black)
- Training Disc Replacement (1)
- (1) Graduation Disc (1)



Assembling Your NEO Flex





The Flair logo on the base and the NEO logo on the post must be on the same side.



Flow-Control vs Bottomless 2-in-1 Portafilter

Flow-Control Portafilter (Red) Featuring a Pressurized Portafilter



All Brewers Should Start Here!

The Flow-Control Portafilter features a restricted exit port, which builds pressure for brewing espresso in the chamber. This portafilter can be used with almost any grinder, or with coarse pre-ground coffee, without the need to "dial-in" your shot. Use for convenience.

Bottomless 2-in-1 Portafilter (Black) Featuring a Removable Spout



Requires a Quality Burr Grinder! You will need to "dial-in," or trial different sized grounds until you get the right pressure. Grind too fine, and you won't be able to lower the lever. Grind too coarse, and the lever will lower without any resistance and not make espresso.

Brewing with Your NEO Flex



Brew Head Separate the brew head into four parts: 1) Piston 2) Brew Cylinder 3) Screen 4) Portafilter. Tip: Use dosing cup to

remove piston.



Brew Cylinder Boil water. Add preheat cap to bottom of brew cylinder. Fill with boiled water. Leave for at least 30 seconds.



Start with the Flow-**Control Portafilter**

Red portafilter – no special grinder required - avoid coffee grounds that are too fine.



Prepare your Freshly Roasted Beans Start with 15 grams of beans or grounds (roughly 3 tablespoons). If grinding, do so right before brewing for the best results.



Tamp Lightly & Evenly on Level Surface



Fill to Line with Brew Water



to Portafilter

Insert Piston On Top of

Filled Cylinder





Lower the Lever!

(See Next Page for Lever Force)




WARNING: 1 Never Release Lever Abruptly! Boiling Water May SPRAY! 2 If Lever Is

Extremely Hard To Lower, Coffee Grounds Are Too Fine *(see next)*

Dialing-In Lever Force

Your Flex comes with two "Training Discs" (red); one of which is installed in the piston. Use this red disc as you learn how much lever force is appropriate. The foil seal of the Training Disc (red) will break if excess force is applied to the lever, indicating that your grounds are too fine. If the foil breaks, water will bleed into the brew head. Reattempt with coarser grounds (try fine sea salt consistency if using Flow Control Portafilter) and retest with the second red disc. Extra discs can be purchased on our site.

Install the "Graduation Disc" (black) once confident that the force applied is never excessive. If trying new coffee with the Graduation Disc and you feel you're applying excessive force on the lever, carefully STOP brewing and start over with coarser grounds.



*Remove by pulling out by the small recess at the edge of the disc. Push new disc into place. All discs must have lettering facing out. Never remove foil of Training Disc.



Follow the steps below. Cleaning your NEO Flex should be done with water only. No soap is needed, as it can affect your espresso's taste. Never put your Flex parts in the dishwasher.



Slowly lift lever and remove assembled Brew Head from NEO Flex frame, gripping the silicone where indicated above.



Detach portafilter over sink by gripping portafilter in one hand and silicone on brew cylinder in other hand, then pull apart.



Remove dispersion screen and eject grounds by knocking them out against the side of a trash can. or dig the grounds out with a utensil.



Remove the piston using the dosing cup. Place cylinder over dosing cup and press down on a hard surface.



Rinse all brewing parts with water from the tap. Reminder, don't use soap as it will impact your espresso's taste.

Troubleshooting your NEO Flex

We recommend periodically flushing your Flow-Control Portafilter and brew head with fresh water. This will prevent the build-up of any coffee residue and ensure optimum flow. Simply follow the brewing steps, without coffee, to flush. For more thorough cleaning, remove the flow-control spout and rinse all pieces with water, as shown below. Leave all portafilter parts disassembled and upside down to dry.

Removable, replaceable spout to enable cleaning and declogging. Each Flex comes with \neg an additional spout. Replace as necessary and if clogged.



Refining Your Brew



To better manage the force on your lever, and the pressure in your system, consider upgrading to our Pressure Gauge Kit.

Or, place your complete Flair on a bathroom scale to help gauge the force applied while brewing. 30-40 pounds is the target. Never surpass 70 pounds!



Our team is here to help! If you experience any challenges, please reach out:

https://flairespresso.com/contact

Your NEO Flex is backed by a 1-year limited warranty. For details visit: https://flairespresso.com/warranty

