WEIGH CUP Quick Start Guide

8.35. T



PRODUCT SPECS

- Max Capacity: 500g
- •Units: g/oz/ml
- Dimensions: 80 x 81 x 90mm
- Division: 0.05g/0.1g
- Display: Digital LED
- Battery: Lithium Rechargable
- Cup Material: Stainless Steel






WARNINGS


- 1. When the display shows 'ERR'. The cup is overweight.
- 2. When the display shows 'UNST'. The cup isn't level.
- 3. When the display shows 'LO'. The cup battery is low.
- 4. The Weigh Cup is not waterproof. Keep dry and do not wash.
- 5. The Weigh Cup is not shock proof and can be broken if dropped.
- 6. 1-year limited warranty for factory defects only.

WHAT'S INCLUDED & COMPONENTS

- Weigh Cup Body
 Type-C USB Cable for Charging
 On/Off Power Switch
- 4 Type-C Charging Port
- **5** Ceramic Dosing Cup

Removable Stainless Steel Cup
 Scale Display with Units
 Options Control Button
 Weigh Cup Manual (not pictured)






- Press and hold (Tr to turn display ON/OFF
- Double-tap (UTT) to turn ON/OFF buzzer
- When display shows '0.00' click (UTT) to change units
- When display shows any weight, click (UTT) to tare/zero
- Display will auto-off after default 120 seconds
- Change auto-off at startup when display reads '8.8.8.8'



Use ON/OFF Switch to cut power
ON/OFF Switch does NOT need to be ON for charging
To ensure correct charging, connect to a computer USB (requires 5v 1a power source)

CERAMIC DOSING CUP

Your Weigh Cup comes with a Ceramic Dosing Cup. Use for dosing beans or as a cup for brewing and drinking your espresso. There are two sides:



CONTACT FLAIR'S CUSTOMER SERVICE

For Troubleshooting: https://flairespresso.com/contact/

